


Version: 1

PMMA TFD System

Products

Plex 1120/Plex 1110
Plex 1510
Plex 1690
Plex 1535
Plex 192
QMI color
Plex Cleaner
Plex Filler



Tools

10015	
Stripholder	
Strip 4700-280- B2	
Wiper	
Nylon roller	
Trowel	
Hollew trowel	

Colors





Version: 1

Step 1: Preparation of the subfloor

On a concrete or cement-bound floor, in many cases a so-called cement veil is present. By (diamond) sanding or blasting this veil disappears. Sanding or blasting is recommended in all cases for optimal adhesion to the subfloor. This also gives concrete floors better impact resistance. Sanding the floor can be done with a rotary parquet sander. The grit size of the sanding disc depends on the subfloor. It would be wise to have several sanding discs on hand.

Step 2 Application of the de Primer

- It is important to primer with tooth strip 4700-280- B2 to ensure the correct layer thickness. If this is done with a roller or trowel there is a risk that the primer is not applied thick enough. Therefore the primer will not cure properly.
- Apply the primer with tooth strip 1700-280- B2
- Scattering is important for building the proper layer thickness of the overall flooring system

Usage Plex 1120 + Plex 192	300-500 gram/m ²
Usage Mortel 0,4-0,8 / 0,8-1,4	600 gram/m ²

Ambient temperature	Catalyst (Plex 192)	Application time	Curing time
0-10 °C	6% on Plex 1120/1110	11 minutes	30 minutes
10-20 °C	4% on Plex 1120/1110	8 minutes	30 minutes
20-30 °C	2% on Plex 1120/1110	8 minutes	30 minutes



Version: 1

Step 3 Repairing holes and an uneven substrate

- The holes and bumps to be repaired must first be primed with Plex 1120, see the previous step.
- Because of the chemical reaction and rapid heat buildup, it is important to add more coarse quartz at deeper holes to keep the product temperature from rising too high. If product temperatures are too high, the mortar comes lose
- Apply with a trowel

For holes up to 2 cm thick, the following is recommended:

	9 10 100011111011110011
Plex 1510	6,3 kg
Mortel 0,4-0,8	25 kg

For holes up to 5 cm thick, the following is recommended:

	g 10 1000111110114041
Plex 1510	6,3 kg
Mortel 0,4-0,8	25 kg
Grind 2-3	5 kg

For holes up to 10 cm thick, the following is recommended:

Plex 1510		6,3 kg
Mortel 0,4-	0,8	25 kg
Grind 2-3		10 kg

Ambient temperature	Catalyst (Plex 192)	Application time	Curing time
0-5 °C	4% on Plex 1510	20 minutes	60 minutes
5-10 °C	3% on Plex 1510	25 minutes	55 minutes
10-20 °C	2% on Plex 1510	17 minutes	35 minutes
20-30 °C	1,5% on Plex 1510	14 minutes	30 minutes



Version: 1

Step 4 Application of the cove

- The application of the cove is done with Plex 1535 + Plex 192 + Mortel 0,4-0,8
- Make sure that the substrate and the raised edges, against which the cove will be placed, have also been pre-treated with primer.
- Work precise and clean. It is important that no skirting residue is left on the substrate; this will be seen in the floor.
- Apply with a plasterer's spatula and apply the cavity with a hollow angle trowel
- Push the cove well, to compact it properly. After pressing the skirting well, brush it with Plex cleaner.

Mixing Ratio

Plex 1535 + Plex 192	1 kg
Mortel 0,4-0,8	3 kg

Ambient temperature	Catalyst (Plex 192)	Application time	Curing time
0-5 °C	4% on Plex 1510	20 minutes	60 minutes
5-10 °C	3% on Plex 1510	25 minutes	55 minutes
10-20 °C	2% on Plex 1510	17 minutes	35 minutes
20-30 °C	1,5% on Plex 1510	14 minutes	30 minutes



Version: 1

Step 5 Application of the Construction layer

- When applying the construction layer, keep the tooth strip holder upright. Check regularly that the teeth of the tooth strip are not worn down!
- Use tooth strip 4676-000-S2 for applying the construction layer.
- Allow the product to flow before you start spreading. Always pour the entire contents
 of the bucket at once to prevent rapid reaction of material in the bucket.
- Scatter the construction layer with Mortel 0,4 0,8 until no wet spots are seen

Construction layer mixing ratio		
Plex 1510		10 kg
Plex filler		20 kg

Usage (Plex 1510 + Plex filler) 2,6 kg/m ²
1 Obage (i lex fore i i lex filler)	/ 2,0 kg/iii

Usage Mortel 0,4-0,8	4 kg/m ²

Ambient temperature	Catalyst (Plex 192)	Application time	Curing time
0-5 °C	4% on Plex 1510	20 minutes	60 minutes
5-10 °C	3% on Plex 1510	25 minutes	55 minutes
10-20 °C	2% on Plex 1510	17 minutes	35 minutes
20-30 °C	1,5% on Plex 1510	14 minutes	30 minutes



Version: 1

Step 6 Application of the topcoat

- Before applying the top coat, remove excess quartz from the floor and vacuum the floor.
- When adding too much catalyst, yellow spots may appear because the top layer then builds up a temperature that is too high.
- The degree of anti-slip depends on the finish
- Apply with a squeegee and roll with a roller

First layer	Plex 1690 + Plex192	250-400 gram/m ²
Optional second layer	Plex 1690 + Plex192	250-400 gram/m ²

Ambient temperature	Catalyst (Plex 192)	Application time	Curing time
0-10 °C	2% on Plex 1690	13-15minutes	35-40 minutes
10-15 °C	1,5% on Plex 1690	13-14 minutes	30-35 minutes
15-20 °C	1% on Plex 1690	13-12 minutes	30-35 minutes
20-30 °C	0,8% on Plex 1690	10-12 minutes	20-30 minutes

Finish			
Heavy antislip	R12	Wiper	500 gram/ m ²
Antislip	R11	Trowel	600 gram/m ²
Light antislip	R10	Wiper 2x	780 gram/m ²

Displacement value for two layers of sealing is V6



Version: 1

Value base

All technical data stated in this technical data sheet is based on laboratory tests. Actual measured data may vary due to circumstances beyond our control.

Health and safety information

For information and advice on how to safely handle, store and dispose of chemical products, users should refer to the most recent material safety data sheet containing physical, ecological, toxicological and other safety related data.

Legal notes

This information, and in particular the recommendations related to the application and end use of Eurostep products, is provided in good faith based on our current knowledge and experience of the products. It is valid for products that are correctly stored, treated and applied under normal conditions in accordance with Eurostep's recommendations.

In practice, differences in materials, substrates and actual on-site conditions are such that no warranty in respect of merchantability or of suitability for a particular purpose, nor any liability arising out of any legal relationship whatsoever, can be inferred either from this information, or from any written recommendations, or from any other advice offered. The user of the products must test the product's suitability for the intended application and purpose. Eurostep reserves the right to change the properties of its products. The proprietary rights of third parties must be observed. All orders are accepted subject to our current terms of sale and delivery. Users must always refer to the most recent issue of the technical data sheet for the product concerned, copies of which will be supplied on request.